

WHAT'S INCLUDED IN THE BATHROOM IN A BOX VANITY PACKAGE?

Each item has a description that details what is included. It is usually the vanity, a drop-in or undermount sink, a wood or stone top and backsplash, and a faucet.

WHAT IF I DON'T WANT THE SINK OR FAUCET THAT IS INCLUDED IN THE BATHROOM IN A BOX VANITY?

These items are boxed at the factory and therefore include all items featured. The faucet is boxed separately and the sink is attached to the vanity with a removable mending plate. There is no discount for unused items. Cole & Co. is unable to process returns or unused items for credit.

WHAT IS THE WARRANTY ON THE VANITY?

There is a one year limited warranty on the vanity and top. Defective product is covered, however, abuse of vanity including water damage is not covered under the limited warranty.

WHAT IS THE WARRANTY ON THE SINK?

There is a one year warranty on the sink.

HOW DO I MAINTAIN THE BRASS SINK?

Brass sinks can give long lasting service and beauty if handled and maintained properly. Brass and copper are durable materials; however, they are soft and can be scratched, scuffed and dented fairly easily. Keep that in mind when bringing glasses, utensils and cleaning materials into contact with the sink.

For ordinary cleaning, use nothing but a soft, clean cloth and mild dish detergent followed by a thorough clear water rinse. Wipe dry with a clean, soft cloth.

Stains and tarnish should be removed with a small amount of good quality brass cleaner. Rub lightly to lift the discoloration, let dry, then polish with a soft, clean, dry cloth.

Minor surface scuff and very light scratches can be removed with a fine automotive rubbing compound followed by brass polish.

Deeper scratches may require wet sanding with "wet or dry" sandpaper followed by rubbing compound, finished with brass polish. The severity of the scratch determines the coarseness of the sandpaper with which to start. For very deep scratches we suggest starting with 220 grit followed by grits of 320, 400 and 600 progressively. In all cases use the finest grit that will work to remove the scratch.

HOW DO I CLEAN THE GREEN FILM WHICH CAN FORM ON THE SURFACE OF THE BRASS SINK?

Over a period of time the solid brass sink may oxidize, resulting in a green film forming on the surface of the sink. It can be easily cleaned with a soft brush and toothpaste.

WHAT'S INCLUDED IN THE BATHROOM IN A BOX VANITY PACKAGE?

Each item has a description that details what is included. It is usually the vanity, a drop-in or undermount sink, a wood or stone top and backsplash, and a faucet.

WHAT IF I DON'T WANT THE SINK OR FAUCET THAT IS INCLUDED IN THE BATHROOM IN A BOX VANITY?

These items are boxed at the factory and therefore include all items featured. The faucet is boxed separately and the sink is attached to the vanity with a removable mending plate. There is no discount for unused items. Cole & Co. is unable to process returns or unused items for credit.

WHAT IS THE WARRANTY ON THE VANITY?

There is a one year limited warranty on the vanity and top. Defective product is covered, however, abuse of vanity including water damage is not covered under the limited warranty.

WHAT IS THE WARRANTY ON THE SINK?

There is a one year warranty on the sink.

HOW DO I MAINTAIN THE BRASS SINK?

Brass sinks can give long lasting service and beauty if handled and maintained properly. Brass and copper are durable materials; however, they are soft and can be scratched, scuffed and dented fairly easily. Keep that in mind when bringing glasses, utensils and cleaning materials into contact with the sink.

For ordinary cleaning, use nothing but a soft, clean cloth and mild dish detergent followed by a thorough clear water rinse. Wipe dry with a clean, soft cloth.

Stains and tarnish should be removed with a small amount of good quality brass cleaner. Rub lightly to lift the discoloration, let dry, then polish with a soft, clean, dry cloth.

Minor surface scuff and very light scratches can be removed with a fine automotive rubbing compound followed by brass polish.

Deeper scratches may require wet sanding with "wet or dry" sandpaper followed by rubbing compound, finished with brass polish. The severity of the scratch determines the coarseness of the sandpaper with which to start. For very deep scratches we suggest starting with 220 grit followed by grits of 320, 400 and 600 progressively. In all cases use the finest grit that will work to remove the scratch.

HOW DO I CLEAN THE GREEN FILM WHICH CAN FORM ON THE SURFACE OF THE BRASS SINK?

Over a period of time the solid brass sink may oxidize, resulting in a green film forming on the surface of the sink. It can be easily cleaned with a soft brush and toothpaste.